

Quick Start Guide



- Power On/Off
- Peak Hold On/Off / Reset
- Weight Units
*Tonne > Kilonewtons
> Kilogrammes > Pounds*
- Tare

AVAILABLE KEYS

BACKLIGHT ON



PAIRING TO A CABLED LOAD CELL

(If purchased separately)



Then press

TO END PAIRING



CONFIGURATION MENU



SCROLL UP



SCROLL DOWN



ENTER

FULL HHP MANUAL DOWNLOAD



HHP

v1.00
Part No:
SU6071